



COBRA COIL™



INSTALLATION INSTRUCTIONS

- Greater Durability
- Superior Strength
- Direct Replacement
- Simple Installation

Fits 14" Jet, Delta, General, Ridgid, Reliant, Sears Contractor, Grizzly and most offshore brands 14" blade tensioning devices.

BANDSAW TENSION SPRING REPLACEMENT

SPRING INSTALLATION INSTRUCTIONS



CAUTION: BE SURE TO DISCONNECT ALL ELECTRICAL POWER FROM SAW BEFORE INSTALLATION.



1. Remove all tension from the bandsaw blade.
2. Remove bandsaw blade.
3. Unscrew tension adjusting rod from square nut and remove tension adjusting rod.
4. Remove original spring away from you until spring is removed from housing.
5. Insert new tension spring in reverse order.
6. Install blade and tension to recommended blade specifications.

Still experiencing issues? Call toll free 888.622.7837 or visit www.carterproducts.com

Follow us for news, tips & product updates!

